






TRACKS SHORTENING INSTRUCTIONS

To always insure that your Eco-Tracks have the right tensity, we provide an easy solution to shorten your tracks. Natural wear will cause any bogie tracks to loosen, however shortening the tracks will increase the lifespan and capacity of your product.



Example 294-644421 EVO 710 x 26.5"





IF FURTHER SHORTENING IS REQUIRED REPEAT STEP 1-4

